



Barproof

바코드 검사 모듈

바코드 데이터 판독
및 품질 등급 검증

The screenshot shows a software window with a red header bar. Below it, there are three product labels for "GlobalVision" headache relief tablets. Each label has a color-coded legend at the top: A (green), B (blue), C (yellow), D (orange), and F (red). The labels provide product information like "Fast acting solution for Quality Control headaches" and "25mg/10mg". Below each label is a barcode and its corresponding barcode ID: 0 2 4 0 1 2 3 4 5 6 7 6, 0 2 4 0 1 2 3 4 5 6 7 6, and 0 2 4 0 1 2 3.

Barcode Details		Grade: B
<input type="checkbox"/> Barcode ID:	1	
<input type="checkbox"/> Magnification:	69.00 %	
<input type="checkbox"/> Max Reflectance:	100.00	
<input type="checkbox"/> Min Reflectance:	A (0.00)	
<input type="checkbox"/> Symbol Contrast:	A (100.00)	
<input type="checkbox"/> Defects:	A (0.00)	
<input type="checkbox"/> Decode:	A (4.00)	
<input type="checkbox"/> Type:	Interleaved 2 of 5	
<input type="checkbox"/> BWR:	0.11 mm	
<input type="checkbox"/> Modulation:	A (100)	
<input type="checkbox"/> Decodability:	A (81)	
<input type="checkbox"/> Min Edge Contrast:	A (100.00)	
<input type="checkbox"/> Decoded value:	024012345676	

혜택



바코드 적합성 검증

바코드로 인해 발생할 수 있는 값 비싼 제품 리콜에서 벗어나십시오.



바코드 기능성 검증

귀하의 포장재의 모든 바코드를 디지털 아트워크 파일 상태에서 확인하십시오.

기능

모든 바코드 자동 인식 및 품질 등급 검증

라벨, 카톤, 프레스 시트와 같은 인쇄물 및 PDF 아트워크와 이미지 파일의 모든 바코드를 자동으로 인식하여 데이터를 판독하고 품질 등급을 판정합니다. 바코드 생성 시점부터 인쇄물까지 품질을 관리하십시오.

산업 표준에 따른 바코드 품질 등급 검증

모든 바코드가 ANSI 및 ISO 15415/15416 표준을 준수하는지 확인하십시오. 바코드 모듈은 좌우 여백 및 배율 상수와 같은 일반적인 프리 프레스 확인 항목을 검사합니다.

파일 상태의 바코드 검사

인쇄 전 아트워크 파일의 바코드를 검사하여 데이터 무결성과 품질을 확인할 수 있습니다. 품질 등급에 따라 다른 색상으로 표시되어 용이한 품질 관리가 가능합니다.



GlobalVision

품질 관리 플랫폼

GlobalVision 한국 대리점 – (주)신광피아이에스
02-6672-3450 / info@iskpis.com / www.iskpis.com